

Instructions for Disassembling a GT1/GT2 Steering Column and Installing Bearings

Scooter Steering Column Disassembly and Bearing Installation Guide

Required Materials and Tools:

- **Tools:**

- Hex keys and screwdrivers set
- Wrenches
- Large sledgehammer (at least 3 kg)
- Angle grinder with metal cutting disk
- Heat gun (capable of reaching temperatures around 500°C)
- M10 threaded rod and 3-4 nuts
- Wide metal washers for the threaded rod
- Wooden or plywood spacers (inner diameter 31-32 mm, thickness 10-15 mm)
- Metal or wooden spacer for hammering

- **Consumables:**

- 2 SKF 32006 bearings
- Thick bearing grease
- Silicone grease (for treating seating surfaces)
- Fine-grit sandpaper (P1000 grit)
- Heavy-duty adhesive tape
- Clean wipes (for removing dust and chips)

- **Auxiliary Equipment:**

- Spiral-cut base of an old lower bearing (used for pressing new bearings)
- Stable supports or wooden boards (to hold the scooter firmly in position)
- Assistant (for tasks like hammering out the steering shaft)

-
1. **Workspace Preparation** Begin by properly organizing your workspace. The task is extensive, complicated, and labor-intensive, so stability is crucial. Securely position the scooter—boards were used, for instance, to ensure it doesn't tip over and remains firmly in place.
 2. **Disassembly - Top to Bottom**
 - Begin by dismantling the scooter from the top down, starting with brake lines and wires.
 - Disconnect the brake lines and seal them thoroughly with adhesive tape.
 - Also, seal the holes on the brake levers using the same tape.
 3. **Steering Column Disassembly**
 - Unscrew and remove the upper handlebar part after disconnecting the internal cable within the steering column.
 - Unscrew one bolt on the folding mechanism of the handlebars to unfold it and access the large internal screw inside the steering column.
 4. **Removing Charging Ports**
 - Unscrew the plastic mounting for the charging ports and remove them together with the mounting.
 - This allows side access to the steering column, where cables and the rear brake line pass.
 5. **Accessing the Controller**
 - Unscrew and remove the scooter deck cover that encloses the main controller.
 - This step ensures wires and the brake line won't kink and can freely exit through the hole near the controller.
 6. **Removing Front Brake System**
 - Unscrew the front brake caliper—this facilitates pulling out the front brake line.
 - Completely remove the front brake line along with the caliper.
 7. **Extracting Wires and Rear Brake Line**
 - Carefully pull out wires and the rear brake line from the steering column through the hole near the controller.
 - Note: soft plastic decorative covers on brake lines (covering bolts near handles) should not be cut—they fit through all holes.
 8. **Steering Column Removal**
 - Unscrew all bolts securing the steering column:
 - One large internal screw inside the column.
 - Several smaller external screws.
 - The centering screw.
 - Remove the front suspension along with shock absorber and wheel.
 - Remove the grey aluminum decorative overlay, exposing the aluminum frame.
 9. **Preparation for Steering Shaft Removal**
 - After these steps, only the steering shaft with two bearings should remain in the column.
 - Screw the large galvanized bolt fully into the steering shaft.
 10. **Hammering Out the Steering Shaft**
 - Required:

- Heat gun (500°C).
- Spacer for striking (metal or dense wood).
- Assistant.
- Heat the upper bearing evenly from all sides, holding the heat gun nozzle 1.5–2 cm away. Smoke from leftover bearing grease indicates readiness.
- Set aside the heat gun, place the spacer on the galvanized bolt.
- The assistant hits the spacer hard with a sledgehammer—two strikes were sufficient to remove the shaft.
- **Important:** Don't use a regular hammer—risk of damage. Only a large sledgehammer is recommended, needing just a few hits.

11. Removing the Lower Bearing

- After extracting the shaft, the lower bearing remains attached.
 - Cut it carefully using the angle grinder, avoiding damage to the seating surface.
 - Steps:
 - First, cut the bearing cage.
 - Then spiral-cut to loosen the bearing.
 - Under tension, it will crack and can then be pried off with a screwdriver.
-

Installation (Pressing) of New Bearings into the Scooter's Steering Column

1. Required Materials and Tools:

- 2 new SKF 32006 bearings;
- Thick bearing grease;
- Spiral-cut base from the old lower bearing (mandatory! Risk of bearing damage without it);
- Wooden or plywood washer spacers (to press bearings into place). Alternatives like plumbing fixtures might work but were not tested.

2. Preparing Seating Surfaces:

- Carefully smooth bearing seating surfaces using very fine sandpaper (P1000).
- Remove any remaining dust or chips using clean wipes.
- Apply a small amount of silicone grease to both upper and lower seating surfaces.

3. Pressing in the Lower Bearing:

- Place the new lower bearing onto the steering shaft.
- Immediately follow with the spiral-cut old bearing base (important! the old base must press against the new bearing's narrow part).
- Next, position thick wooden or plywood washer spacers.
- Gradually press the bearing downward by tightening the large galvanized bolt.
- Initially, the bearing will settle into the first seat.
- Gradually add more spacers to push the bearing deeper.

- Important: Ensure the bearing isn't pressed too far—seating must be precise.

4. **Installing Bearing Races in the Steering Column:**

- Use:
 - Metal washers;
 - M10 threaded rod with two lock nuts.
- First, install the lower bearing race.
- Thread the rod with washers through the lower bearing race and column from below.
- Place atop the rod:
 1. Wooden washer (to protect the scooter's aluminum);
 2. Metal washer;
 3. Tighten the nut on the rod.
- Tightening the top nut gently pulls the lower bearing race into position.
- Repeat this procedure for the **upper** bearing race.

5. **Installing the Steering Shaft and Upper Bearing:**

- Insert the steering shaft with the installed lower bearing into the steering column.
- Slide on the upper bearing.
- Immediately add the same spiral-cut old bearing base.
- Using the same thick wooden spacers from the lower bearing installation, tighten the top bolt.
- **Important:** Don't fully tighten the bearing—leave slight technological clearance. Final tightening during assembly will eliminate this clearance without risking over-tightening and jamming.

6. **Completing Assembly:**

- After pressing all components, assemble the steering column in reverse order, exactly repeating disassembly steps.

Note: Minor operations are omitted here, assuming familiarity with general procedures—such as installing rubber plugs or gaskets—which should be obvious to anyone performing this task.

Revision #3

Created 3 May 2025 10:02:46 by Svetlov

Updated 3 May 2025 10:52:50 by Svetlov